



ASSEMBLY PROCEDURES:

1. ATTACH END DAM WITH #8 SCREWS PROVIDED (ONE END DAM PER END). BACK SEAL AS SHOWN, AND TOOL INTO JOINT.
2. CUT JAMB RECEPTOR TO FIT BETWEEN EXTERIOR LEGS OF HEAD RECEPTOR & SUBSILL. BACK SEAL AND TOOL INTO PLACE ALL RECEPTOR TO RECEPTOR AND ALSO RECEPTOR TO SUBSILL JOINTS.